



We Provide The Best Service



USER GUIDE

WELCOME TO Wecare

A smart locator and phone for kids

Wecare helps children stay in touch with their parents, and helps parents know where their children are. The Wecare watch is worn by your child syncs with a smartphone application on the parents phone. This allows the parent to see where their child is at any point in time.

There are a couple of important things to do before your child starts using Wecare watch.

Charging the battery

Wecare has been supplied with general Micro USB line, Charge your new watch for at least 4 hours before using it for the first time.

The standby time of Wecare watch depends on usage. We recommend you set the GPS frequency to save power.



Insert SIM card

Please insert the Micro sim card like following way.



Using the kid phone watch

Power on: Press and hold power key to power on the watch;

Main Menu: Double click touch screen to enter main menu and slide from down to up direction to return main menu

Shortcuts:

Phone call: Slide touch panel from left to right to enter phonebook and make phone call (please bind the watch firstly and add family contacts via APP) ;

Micro chat: Slide touch panel from up to down to enter Micro chat with family contacts

Theme: Slide touch screen from down to up to enter theme settings

Friend list: Slide touch screen from right to left to enter friend list (pls add friend in the main menu ,only same type device can be added as friend)



Downloading the Wecare smartphone app

It's possible to monitor your child's Wecare watch from an Apple or Android smartphone. There's a free Wecare app available in the Apple App Store and in the Android Google Play shop, pls seach it via key words "Wecare"

DOWNLOADING



STEP 1 Download the WeCare app

First, search for the official free WeCare app via scanning the right QR code to download wecare application for your Iphone and android device.

After the app has been installed, open it by tapping the WeCare icon on your phone's screen. If you have purchased your first WeCare watch, hit CREATE NEW ACCOUNT and then continue to Step 2. If you have already created an account for another WeCare watch, sign in and skip to Step 3.

Make sure your Sim data has been activated

If your SIM data was activated when you purchased the watch, simply follow the WeCare set-up instructions below.

STEP 2 Create a WeCare account

Enter your mobile phone number which is using in your mobile.

Now enter YOUR email address for getting password back once you forget it..

For security, please setup your personal password ,choose “The term of service”, the click ✓

Read the terms of service carefully and if you accept, select Agree

Select activate your WeCare watch to move to step 3

A screenshot of a mobile application's registration screen. The title bar is green with a white checkmark and the text 'Quick register'. Below the title bar, there are several input fields: 'Region' with a globe icon and 'China' selected; '+86 Phone number' with a phone icon; 'Email' with an envelope icon; 'Enter New Password' with a lock icon; 'Confirm New Password' with a lock icon; and a checkbox labeled 'I have read and agree to the terms of service' with a link to 'the terms of service'.

STEP 3

Connect to Wecare

Turn on your watch by holding down the key button. Select the country, and then enter the telephone number of the Wecare watch.

Please remember to add this number to your contacts.

Create a profile for your child by entering the required details and attaching a photo. Select NEXT to save your settings and move on to the next section.

You will automatically be the Admin contact and you can enter up to 10 additional contacts manually via family contacts. These are the only 10 contacts that can communicate with your child's Wecare watch.

After clicking ✓, your registration is complete. The Wecare watch will not appear in your online account until it's fully charged, switched on and has connected itself to the cellular network.

Other options can now be set up via the smartphone app.

Attention: If there is short numbers, please input otherwise may affect the calling function.

4G 45% 11:00

Binding ✓

Region China

Watch +86 Please input watch number

Child's Admin

Child's Name Please enter child's Name

IMEI Optional

You must know:

1. Please insert a SIM card, press the power on/off key for a while to power on, and then press repeatedly the key to see if the GSM signal is normal.
2. The SIM card should open Call, SMS, GPRS(>30M/Month), Caller ID etc.
3. If there are no open Caller ID, the watch can't block the incoming call from a stranger.


USING THE WECARE SMARTPHONE APP



Main screen

Tap the Wecare icon to open the smartphone app. Log in you'll see a central 'wheel' with five options:

- Locate: check the location of your Wecare watch on a map
- Call: make a voice call to your Wecare watch.
- Message: send an message to your Wecare watch.
- Frequency: setup updating location automatically in certain time.



Left-hand settings screen

Swiping a finger across the screen from the left-hand side to the right reveals options to change the settings for your Wecare.

My baby: Selecting 'My baby' at the top of the screen takes you to the baby profile screen, which lets you edit your baby's information. Remember to tap ✓ when you've finished.

Remind: Push Notifications for SafeZones, Low Battery etc.

Safe zone: you can set safe zone and will get information when the watch is in or out of safe zones, for better experience, please setup frequency firstly to get safe zone information on time.

Family contacts: you can add 10 entries family numbers here for communications with the watch.

Location: (map view) screen

There are five basic options from the Locate screen:

USING THE WECARE SMARTPHONE APP

SafeZones

WeCare lets parents define 'SafeZones'. If safe zones are set, messages will be received if your child enters or leaves the designated SafeZone.

Choosing the SafeZones button on the main screen allows you to view and edit all the SafeZones that have been set up for the account who bound the watch.



OVERVIEW

These short cut icons allow you to locate and track, and send an SMS or Call.

In addition, you can create, edit or delete information in the following areas

- Real-time location
- Message remind
- Safe Zones
- Family contacts
- My baby
- tracking history
- View watch settings

Contacts

The screenshot shows a mobile application interface for adding a contact. At the top, there is a green header with a back arrow, the word 'Add', and a checkmark. Below the header, a grey note reads: 'The first binding phone will be main family number.' The form contains several input fields: 'Region' with a globe icon, 'baby's' with a dropdown menu showing 'Please input relation', 'Child's Name' with a placeholder 'Please enter child's Name', 'phone number' with a placeholder '+86 Please input phone number', and 'short number' with a placeholder 'Please input short number'. At the bottom, there is a grey box with a warning: 'PS: If there is short numbers between watch and phone number. Please set otherwise the watch cannot receive calls.' A circular button is visible at the bottom right of the form.

The account holder will automatically be stored as the primary number. You can add up to 10 additional contacts and by selecting these from your address book, or manually entering the information.

Once you add a contact, they will be automatically defaulted to be an emergency contact. Press and hold power key of the watch ,all the contacts in the watch will received SOS information and SOS short message.

Tap SAVE when you've added, edited, or deleted any contact information.

The emergency service number should NOT be stored as a contact on the Wecare watch. Similarly, emergency service number for other countries should not be stored as contacts.

OVERVIEW

Important notice

Please note that Wecare should not be regarded as a substitute for the personal care and supervision of any person using the product.

Due to the nature of wireless communications, transmission and reception of data can never be guaranteed. Data may be delayed, corrupted (or be totally lost. Although significant delays or losses of data are rare when wireless watches such as the Wecare product solution are used in a normal manner with a well-constructed network, Wecare company accepts no responsibility for damages of any kind resulting from delays or errors in data transmitted or received using its products, or for failure of its products to transmit or receive such data.